USA Tech Support 800-507-2338 ext. 114



## ANTI-ROLL KIT: E40-34-001-01-01

Vehicle

24+ INEOS GRENADIER

Notes

3-WAY ADJUSTABLE REAR SWAY BAR

Kit Contents	Description	Part Number	Quantity
	REAR SWAY BAR	AS41-34-001-01-RA	1
	HARDWARE KIT	AK41-34-001-01-RA	1


Notes	Read all instructions before beginning installation	
	<ul> <li>Only qualified mechanics experienced in the installation and removal of suspension components should perform this installation.</li> </ul>	
	<ul> <li>Use of a hoist and screw jack is highly recommended and will substantially reduce installation time.</li> </ul>	
	<ul> <li>Never work on or under a vehicle unless it is properly supported by safety stands and wheels are blocked.</li> </ul>	
	<ul> <li>Never use impact wrenches or impact guns to install or remove shock absorber piston components, shafts and Piston rod nuts.</li> </ul>	
	<ul> <li>All Eibach springs should be installed with the Eibach logo right-side-up.</li> </ul>	
	After Installation, inspect and adjust the following: Wheel Alignment; tire/wheel fender	
	clearance when using aftermarket wheels or tires; brake line clearance and attachments; anti-lock-brake system sensors.	



1. Lift and support the vehicle.



2. Use an 18mm to remove the left and right sway bar end links at the sway bar end.



3. Use an 18mm to remove the left and right sway bar brackets. Remove the rear sway bar from the vehicle.




4. Apply the supplied grease to the inside of the new left and right sway bar bushings. Install the bushings on the bar to the inside of the locating tabs.



5. Install new Eibach sway bar brackets on left and right using an 18mm. Tighten to manufacturer specification.



6. Select the sway bar setting by installing the sway bar end link on the end of the sway bar using an 18mm. Position 1 will provide the softest setting. Position 3 will provide the firmest setting.



7. Install the left and right sway bar end links. Tighten to manufacturer specifications.



8. Lower the vehicle and test drive while listening for any abnormal noises